

DOCKTON WATER ASSOCIATION STANDARD OPERATING PROCEDURE FOR TAKING A CHLORINE RESIDUAL.

Collect sample in glass sample vial. Rinse sample cell & cap three times before filling with sample. Measure three times report median.

Low Range/Free

1. Confirm PC2 in low range mode (LR).
2. The blank: fill "free" sample cell to 10ml line and cap.
3. Clean with lab wipe.
4. Insert blank in PC2. Dimond towards keypad, close securely.
5. Press zero button.
6. Add "free" reagent (10ml reagent packets).
7. Swirl for twenty seconds. Wipe cell. Reinsert Dimond towards key pad and cap, wait thirty seconds then press the blue button.

Dave Stoltz
December 2, 2022